



Style#
TP971F



FUSIBLE

Quilting: Fleece

Fusible Thermolam® Plus

High Loft Iron-On Fleece

Pellon® Fusible Thermolam® Plus is an extra lofty, needled fleece with fusible adhesive on one side. It is great for crafts, home decorating, and quilting projects. Fusible Thermolam® Plus will remain lofty after fusing and can be used on fabric, cardboard, or wood.

Note: Always pre-test with a swatch of your fabric prior to use to make sure it is compatible with the fusible. It is recommended to pre-wash all fabrics to remove any coatings that might interfere with the fusible. Do not use fabric softener.

General Directions:

For Fabric

1. Cut Fusible Thermolam Plus and fabric to desired size and shape.
2. Place fleece, fusible (rough or bumpy) side up on the ironing board. Place fabric, right side up, on top of fleece.
3. Cover fleece and fabric with a damp press cloth and with iron on wool/steam setting, press down firmly for 10-15 seconds. Repeat, lifting and slightly overlapping until all fabric is fused.



For Cardboard or Wood

1. Cut Fusible Thermolam Plus and fabric to desired size.
2. Place fleece, fusible side down, on surface to be padded.
3. Cover fleece with a dry press doth. With iron at wool setting (no steam), press for 10-15 seconds in place. Repeat slightly overlapping, until entire area is fused.

Fiber Content: 100% Polyester
Care Instructions: Machine wash warm on gentle cycle, tumble dry low or dry clean.

Project: Planetary Mini Quilt
Designer: Sara Lawson
Skill Level: Beginner



For free project ideas and patterns, visit www.PellonProjects.com
Customer Service – US & Canada 1.800.223.5275, M-F 8a-6p EST



Estilo#
TP971F



FUSIBLE

Acolchados: Vellón

Fusible Thermolam® Plus

Vellón de Alta Densidad Para Planchar

Pellon® Fusible Thermolam® Plus es un vellón de punto de alta densidad con adhesivo de un faz. Es ideal para manualidades, accesorios para el hogar y acolchados. Fusible Thermolam Plus mantendrá su densidad aun después de ser adherido y puede ser utilizado con telas, cartón y madera.

Nota: Pre lavar la tela a utilizar antes de fusionar. No utilice suavizante. Extra Loft Fusible Fleece no requiere ser prelavado.

Direcciones de Uso:

Para Tela

1. Corte Fusible Thermolam Plus y la tela al tamaño y forma deseada.
2. Sobre el planchador coloque el lado adhesivo (áspero o abultado) del vellón hacia arriba. Coloque la tela encima del vellón con el lado derecho hacia arriba.
3. Cubrir la tela y el fleece con un paño húmedo. Coloque la plancha en modo "Lana/Vapor" y planche por 10-15 segundos. Repita, sobreponiendo la plancha por todo el área hasta que se adhiera por completo.



Para Cartón o Madera

1. Corte Fusible Thermolam Plus y la tela al tamaño deseado.
2. Coloque el lado adhesivo del fleece en la superficie a usar.
3. Cubra el vellón y la tela con un paño seco. Con la plancha a temperatura "Lana/Vapor" planche de 10-15 segundos. Repita obreponiendo la plancha por todo el área hasta que

Contentenido de Fibra: 100% Poliéster
Instrucciones de Mantenimiento: Lave a máquina con agua tibia en ciclo suave, use secadora a baja temperatura o limpie en seco.

Proyecto: Planetary Mini Quilt
Diseñadora: Sara Lawson
Nivel: Principiante



Para ideas de proyectos libres y patrones, visita www.PellonProjects.com
Servicio al Cliente – US y Canadá 1.800.223.5275, L-V 8a-6p EST