



Style#
553



EMBROIDERY WASH AWAY

Sol-U-Film Lite™

WASH-AWAY EMBROIDERY STABILIZER

Sol-U-Film Lite™ adds body and support during stitching. When the work is done, simply submerge project in water. This lightweight stabilizer dissolves away easily and cleanly, leaving no trace on either side of project.

GENERAL DIRECTIONS:

How to Use as a Stabilizer

1. Secure Sol-U-Film Lite™ underneath fabric using a hoop or pins.
2. Stitch desired area.
3. Upon completion of stitching, gently tear or trim away excess Sol-U-Film Lite™. To remove all traces of the stabilizer, submerge project in any temperature water for 30 seconds to 2 minutes, then iron dry using a press cloth.



Alternative Removal

- Iron project between two damp paper towels or press cloths.

TIPS:

- For a liquid stabilizer or temporary adhesive, dissolve 1 yard of Sol-U-Film Lite™ in 8 ounces of water and brush onto fabric.
- For stronger stabilization, iron 2-3 layers together with a press cloth and dry iron.

PELLON PROJECTS:



Project: Embroidered Bib
Designer: Judy Steward
Level: Basic

Simple embroidery to turn any bib into a work of art!
Get the complete pattern at www.PellonProjects.com

ADDITIONAL PROJECT IDEAS:

Use Sol-U-Film Lite™ for projects in:

- **Apparel:** Monogramming, ideal for napped fabrics, lace work & decorative stitching.

Fiber Content:

100% PVA (Polyvinyl Alcohol), Acid Free

Care Instructions:

100% Water soluble, any temperature

For more information go to www.pelloninstructions.com

Free projects using this and other Pellon® products at
www.PellonProjects.com or call 1-800-223-5275.



Serie#
553



BORDADOS SOLUBLES

Sol-U-Film Lite™

ESTABILIZADOR SOLUBLE DE BORDADO

Sol-U-Film Lite™ agrega firmeza y cuerpo al momento de bordar. Al terminar, sumerja en agua la pieza bordada para retirar el exceso del estabilizador. Este liviano estabilizador se disuelve fácilmente y no deja rastro en la tela.

DIRECCIONES DE USO:

Para Aplicación como Estabilizador

1. Asegure Sol-U-Film Lite™ debajo de la tela con un aro de bordado o con imperdibles.
2. Zurza área deseada.
3. Al terminar jale suavemente o recorte el exceso de Sol-U-Film Lite™. Para retirar el resto del estabilizador, sumerja el bordado por 30 segundos a 2 minutos en agua. Seque con la plancha utilizando una tela de planchado.



Método Alternativo

- Plancha el bordado entre dos piezas de papel toalla o telas de planchado que estén húmedos.

SUGERENCIAS:

- Para ser utilizado como estabilizador liquido o adhesivo temporal, disuelva 1 yarda de Sol-U-Film Lite™ en 8 onzas de agua y aplique a la tela.
- Para mayor firmeza utilice 2-3 capas del estabilizador, seque con plancha usando telas de planchado.

PELLON PROJECTS:



Proyecto: Babero Bordado
Diseñadora: Judy Steward
Nivel: Básico

Convierta cualquier simple babero en obra de arte solo con un bordado! Obtenga este patrón en www.PellonProjects.com

MAS IDEAS PARA PROYECTOS:

Utilice Sol-U-Film Lite™ en proyectos para:

- **Accesorios:** Ideal para telas aterciopeladas, encajes Monogramas y bordados decorativos.

Contenido de Fibra:

100% PVA (Polyvinyl Alcohol), Acid Free

Instrucciones de Mantenimiento:

100% Soluble en agua de cualquier temperatura

Para mayor información visite www.pelloninstructions.com

Para proyectos gratis de este y otros productos de Pellon®
visite www.PellonProjects.com o llame al 1-800-223-5275.

