

iPad or Laptop Case

Skill Level: Intermediate

Designed By
Amy Ellis

www.amyscreativeside.com



This iPad or laptop case will make a perfectly sized pouch for your favorite electronics. Two sizes are provided for a matching set or customize your own size. Example shown uses fabrics by Hokkoh.

Materials Needed

Variety of fabrics, scraps, fat quarters or yardage (will vary according to the size of your electronic)

1 yard 809 Décor Bond[®]

2 layers of Legacy[™] by Pellon Natural Cotton Batting NB-96

1 yard Lining Fabric

4-6" of sew-in Velcro[®]

Tools Needed

Sewing Machine and Related Supplies

Rotary Cutting Tools

Instructions:

Step 1: Determine the size of your device

ipad2 :The ipad measures 9.5" x 7.25". Cut your fabrics to 11" x 19". For exterior strips cut eight 3" x 11" pieces.

Laptop: The laptop measures 15.5" x 10.5". Cut your fabrics to 18" x 27". For exterior strips cut nine 3.5" x 18" pieces.

For other devices:

L x 1.15

W x 2.6

To simplify round your numbers to the nearest 1/2"

2: Cut your fabrics then piece the exterior, lining if necessary.



3: Add Décor Bond, according to the manufacturer's directions to both the exterior and the lining.

4: Add two layers of Legacy™ by Pellon Natural Cotton Batting to the exterior piece.

Baste and quilt. Example shown uses simple straight lines. Trim away excess batting after quilting.

5: Add a curve to one end of both the exterior and the lining

Tip: Use a dish or cup for the perfect curve.



Instructions:

6: Add the Velcro. Placement of the velcro will depend on the size of your device. Hint: Fold the layers around your device to aid in placement.

Place the exterior velcro on the straight edge a few inches down. Place the lining about an inch away from the edge of the curved edge. Sew the velcro in place making sure to secure with extra stitches.



7: To sew up the sides determine the size of the pocket. For the laptop case the pocket is 8.5" and the iPad pocket is 6.5". Hint: Try on your device to determine the best pocket size. Using a 3/8" seam allowance, sew the lining and leave an opening on one side. Sew an inch on top and bottom and reverse to lock stitches. Also, leave 3/8" unsewn at the top of your pocket.



8: Turn the lining right side out and tuck inside the exterior. Pin around the top pocket and flap.



Instructions:

9: Sew around the entire length. Turning the corners will be tight. Stop to adjust if necessary. Clip away the excess from the bottom corners and turn right side out.



10: Close the opening in the lining. Tuck, pin and sew. Tuck the lining inside and press.



11: Pin to ensure lining stays in place and topstitch.

