



Style#
807



Fusible Webs & Adhesives: No Backing

Wonder-Web®

Fusible Web with No Backing

Pellon® 807 Wonder-Web® is an unsupported, fusible web that bonds fabric to fabric or any porous surface such as wood or cardboard. It is great for use in a wide range of apparel, home décor, and craft projects. Wonder-Web fuses easily in seconds and retains a soft hand after fusing. It is excellent for use when the paper-backing is not needed.

Notes:

Always pre-test with a swatch of your fabric prior to use to make sure it is compatible with the fusible. It is recommended to pre-wash all fabrics to remove any coatings that might interfere with the fusible. Do not use fabric

General Directions:

1. Pre-heat iron to a Wool/Steam setting.
2. Cut Wonder-Web and fabric to desired size.
3. Place Wonder-Web between fabric layers. Cover with damp press cloth and press firmly in place for 10 seconds. Do not slide iron. Repeat, lifting and slightly overlapping iron until all fusing is complete. Let cool.
4. Press from other side to remove excess moisture.



Tips:

- Use steam iron with metal sole plate. Hand-held steamers will not permanently bond interfacing to fabric.
- Use a damp press cloth as a temperature and timing guide. After 10-15 seconds, press cloth should be almost dry. If not, raise iron temperature or hold iron in place a few seconds longer.

Fiber Content: 100% Polyester
Care Instructions: Machine wash warm.
Tumble dry low or dry clean.

Pellon Project:
Sweet and Tiny Keychain
Designer: Emily Lang
Skill Level: Beginner



For free project ideas and patterns, visit www.PellonProjects.com
Customer Service – US & Canada 1.800.223.5275, M–F 8a–6p EST



Style#
807



Tejidos de Fusión y Termoadhesivos: Sin Soporte de Papel

Wonder-Web®

Web fusible sin respaldo

La entretela tejida fusionable Wonder-Web® reemplaza la costura o el pegamento. Fusiona una tela con otra tela o con una superficie porosa como madera o cartón o cualquier otra superficie porosa. Excelente para la decoración en el hogar, proyectos de costura y manualidades. Excelente para cortar en tiras y usar en el ruedo de pantalones y faldas!

Nota: SIEMPRE REALIZE UNA PRUEBA EN UN PEDAZO DE TELA ANTES DE USAR PARA VERIFICAR QUE ES COMPATIBLE CON EL ADHESIVO.

Instrucciones Generales:

1. Precaliente su plancha en la posición para lana/vapor.
2. Corte su pieza de Wonder-Web y tela de acuerdo al tamaño deseado.
3. Coloque el Wonder-Web entre dos capas de telas. Cubra con un paño húmedo y con la plancha en la posición Lana/Vapor presionando FIRMEMENTE por 10 segundos sin mover de lugar.
4. Presione desde el otro lado para remover humedad excesiva.



Tips:

- El Wonder-Web es lavable a máquina o en seco en la tintorería. No use suavizante de telas.
- Utilice su paño húmedo como una guía de temperatura para su plancha. Cuando usted levante la plancha para moverla a la sección siguiente, el paño para presionar debería de estar casi seco. De lo contrario, puede ser que usted necesite ajustar la temperatura de su plancha o presionar por un poco más de tiempo en el mismo lugar.

Contenido de Fibra: 100% Polyester
Instrucciones de Mantenimiento: Lavar a máquina en agua tibia, en ciclo delicado y secar en temperatura baja o lavar al seco.

Pellon Proyecto:
Sweet and Tiny Keychain
Diseñadora: Emily Lang
Nivel: Principiante



Para ideas de proyectos libres y patrones, visita www.PellonProjects.com
Servicio al Cliente – US y Canadá 1.800.223.5275, L–V 8a–6p EST