

Wrap-N-Zap™ Potato Zapper

Skill Level: Beginner

Sewn By
Connie Watkins



Use 100% natural cotton batting Wrap-N-Zap™ to create a handy potato zapper. It works in the microwave to help retain moisture for steamy potatoes. This is a fun family project and makes a great gift item.

IMPORTANT! When cooking any vegetable wrapped in fabric, limit the time to two minute intervals. Pellon® does not recommend cooking on high longer than two minutes. When longer cooking time is needed, stop, turn the item, then start again. Never leave a microwave unattended while cooking. Use only 100% cotton fabrics and trims.

Fabrics Needed

Outer Fabric - 100% Cotton Only	1 fat quarter
Lining fabric - 100% Cotton Only	1 fat quarter

Materials Needed


Pellon® WZ-45 Wrap-N-Zap™	1 package (45" x 36")
Thread	

Tools Needed


Sewing machine and related supplies
Rotary cutter and related supplies

Cutting and Assembly Instructions

Cut one 9" x 20" rectangle from the outside fabric.
Cut one 9" x 20" rectangle from the lining fabric.
Cut one 9" x 20" rectangle from the Wrap-N-Zap™.




Print and cut out the triangle template on the dashed line, found on the template page. Place the template over one of the rectangles as shown.



Trace the triangle point onto the fabric. Cut on drawn line.


Repeat with the other two rectangles.

Place the outer fabric and lining fabric right sides together with the Wrap-N-Zap™ batting against the wrong side of the lining fabric. Stitch around the perimeter using a 1/2" seam allowance and leaving a 3" gap on one of the sides for turning.




Trim seams. Cut corners on a slant. Turn potato zapper right sides out. Poke out corners. Turn opening in on seam allowance. Align and pin the edge shut.

Fold short straight edge up until edge is 1" from the triangle sides. Align edges and pin. Topstitch using a 1/4" seam allowance along the sides of the potato zapper, backstitching on both sides to reinforce the end.



Wrap-N-Zap Triangle Top Template

Set printer to print at 100% and print template. Follow instructions for placement and cutting..



Triangle Flap Template